Installation Guide

Plati 115 Corner Freestanding Bath

Important — Read this first!


1. Inspect the bath **before installation** to ensure there are no visible defects. If a defect is found, do not install the bath and contact the supplier immediately. Claims for defects will not be accepted after the product has been installed.
2. The bath must be installed by a **licensed tradesperson**. Failure to do so may void the warranty.
3. Compliance with **AS.3740 Waterproofing of Wet Areas within Residential Buildings** applies when installing baths.
4. **Local authorities** may have specific installation requirements and this should be checked before installation.
5. Grade the **bath sub-floor** in accordance with requirements of local authorities. Grade sub-floor 1:60 minimum.

Installation Notes


1. Use acetic cured silicone sealant. Do not use epoxy type adhesives.
2. Always use the actual product to verify placement.
3. The bath is supplied with four adjustable support feet on the base frame of the bath.
   - Position the bath into place and use the adjustable support feet to ensure that the bath is level. Leave a 3mm void between the base of the bath and the floor.
   - Use silicone around the base, to seal the bath to the floor. Allow a 20mm gap in the silicone seal, to act as a weephole (the gap is designed to reveal any plumbing leakage).


Warning! *Failure to level the bath correctly may damage the bath structure and cause cracking.*

Right Corner Bath



Left Corner Bath





Bath has integrated overflow

SEIMA

kitchen + laundry + bathroom ware

seima.com.au

Please note
- All measurements are in millimetres.
- Dimensions are nominal and subject to normal ceramic manufacturing variations of ±5mm.
- Fixing: Use acetic cured silicone sealant. Do not use epoxy type adhesives.
- Specifications may vary without notice as part of our continuous improvement practices.
- Clean with a damp cloth. Do not use abrasive cleaners, liquids or pastes.